

Jump Wall

2m - MA-025


3m - MA-017

How to play the game:

1. Adjust the hoop height.
2. Start at the red line.
3. Run and jump as far as you can into the coloured area to pick a colour.
4. Run to your colour and throw the ball or bean bag into the netball hoop or try to bounce a ball off the corner of the Kerby.



Markings MA-905 (optional extra with an additional cost)



MultiActive - Game Walls and Markings

MultiActive encourages all children, regardless of ability, to gain confidence with sports, teamwork and mathematical thinking. Regular play supports children's general health and fitness, while building hand-eye and foot-eye coordination.